ZANUSSI

# LAVAVAJILLAS
# DISHWASHER
# MÁQUINA DE LAVAR LOIÇA

## DA 6252


| | | |
|---|---|---|
| E | Manual de instrucciones - parte 2 | 2 |
| GB | Instruction book - part 2 | 11 |
| P | Instruções de utilização - parte 2 | 19 |

# Description of the appliance




**1.** Water hardness adjustment

**2.** Levelling spacers

**3.** Upper basket stop

**4.** Salt container

**5.** Large filter

**6.** Detergent dispenser

**7.** Control panel

**8.** Rating plate

**9.** Rinse aid dispenser

**10.** Central filter

**11.** Lower spray arm

**12.** Upper spray arm

**13.** Upper basket

**14.** Worktop

# The control panel




## 1. On/Off indicator light

## 2. On/Off push button

## 3. Main wash temperature push button (50°)

## 4. Half load push button

By pressing this push button washing can be confined to the only lower basket.

This is useful when only a few dishes need washing (see "Washing programmes" chart).

Remember to load all the dishes **only in the lower basket.**

## 5. Door handle

## 6. Programme marker

## 7. Programme selector dial

## 8. Programme guide

# Washing programmes

| Programme | Degree of soil and type of load | Starting position of the programme selector | Required push buttons | Recommended quantity of detergent | | Cycle description |
|---|---|---|---|---|---|---|
| | | | | wash | prewash | |
| **Normal 65°C with prewash** | Normal soil.<br>Crockery and cutlery | **A** | **On/Off** | 25 g | 5 g | Cold prewash<br>Main wash up to 65°C<br>1 cold rinse<br>1 hot rinse<br>Active drying |
| *** Bio 50°C** | Normal soil.<br>Crockery and cutlery | **A** | **On/Off**<br>**+**<br>**50°** | 25 g | 5 g | Cold prewash<br>Main wash up to 50°C<br>1 cold rinse<br>1 hot rinse<br>Active drying |
| **Normal 65°C no prewash** | Light soil.<br>Crockery and cutlery | **B** | **On/Off** | 30 g | / | Main wash up to 65°C<br>1 cold rinse<br>1 hot rinse<br>Active drying |
| **** Quick 50°C** | Light soil.<br>Crockery and party crockery | **C** | **On/Off**<br>**+**<br>**50°** | 30 g | / | Main wash up to 50°C<br>1 cold rinse<br>1 hot rinse |
| **Rinse and Hold** | Any.<br>Partial load (to be completed later in the day). | **D** | **On/Off** | / | / | 1 cold rinse<br>(to avoid food scraps from sticking together). |
| **Half load** (Normal no prewash) | Light soil.<br>Crockery and cutlery | **B** | **On/Off**<br>**+**<br>1/2 | 20 g | / | Main wash up to 50°C<br>1 cold rinse<br>1 hot rinse<br>Active drying |
| **Half load** (Quick) | Light soil.<br>Crockery and party crockery | **C** | **On/Off**<br>**+**<br>1/2 | 20 g | / | Main wash up to 50°C<br>1 cold rinse<br>1 hot rinse |

***** Testing programme for EN 50242. (see "Hints for test centres").

****** This is a special programme for quick washing a full load of lightly soiled dishes, glasses and crockery (except pots) so that you may re-use them promptly.

# Operating sequence

## 1. Check the filters

Ensure that they are clean and properly positioned. **(See "Maintenance and cleaning" - Instruction book - part 1)**

## 2. Check that there is rinse aid and salt

**(See "Instruction book" - part 1)**

## 3. Load the dishes

Remove any scraps of food.

Pull the lower basket out and arrange the saucepans, plates and cutlery in it.

Pull the upper basket out and arrange the plates, saucers, glasses and cups etc. in it.

Slide the baskets back into the machine.

## 4. Ensure that the spray arms can rotate freely

## 5. Measure out detergent

Add the detergent into the dispenser according to the dosage quantity given in the "Washing programmes" chart.

Close the detergent dispenser lid.

## 6. Close the dishwasher door

## 7. Set the programme

Turn the programme selector dial clockwise until the letter of the programme you wish to select corresponds with the programme marker on the control panel.

If necessary select the temperature of the main wash (or a half load programme) according to the instructions in the "Washing programmes" chart (see "Required push buttons").

## 8. Start the programme

Depress the On/Off push button.

The On/Off indicator light will come on and the machine will start.

If you wish to interrupt the washing programme at any time press this button again.

## 9. At the end of the washing programme

At the end of the programme the dishwasher will automatically stop.

The On/Off indicator light remains on until the On/Off push button is depressed.

## 10. Switch off the dishwasher

Switch off the dishwasher by pressing the On/Off push button.

**Wait 15/20 minutes before opening the dishwasher's door;** in this way you will avoid burning yourself when removing the dishes and avoid also the damage of the nearby furniture caused by the escape of steam**.**

Empty the lower basket first and then the upper one; this will avoid water dripping from the upper basket onto the dishes in the lower one.

**When the washing programme has finished, it is recommended that the dishwasher is unplugged and the water tap turned off.**

**In general it is not advisable to open the door while the machine is working; if the door is opened however, a safety device ensures that the machine stops.**

**Important!**
**Care must be taken if the door is opened during the hot phase or immediately after a programme has finished, as steam may escape.**

# Using your appliance

## Loading your appliance

Before placing dishes in the machine, remove any scraps of food, to avoid clogging the filters and consequently reducing the performance.

**Do not load very small items which can fall through the baskets.**




## The lower basket

The lower basket is designed to take saucepans, lids, plates, salad bowls, cutlery etc.

Large dishes and lids should be arranged around the edge of the basket, ensuring that the upper spray arm can turn freely.




The two rear rows of prongs on the lower basket can be easily lowered to allow you to load pots, pans and bowls.

**To lower the prongs:**

- Slightly pull them upwards and let them drop down (see picture).
- To bring them back to the standing position, just pull them up again.







## The cutlery basket

**Long bladed knives stored in an upright position are a potential hazard.**
**Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.**
**Take care when loading or unloading sharp items such as knives.**

Cutlery should be placed in the removable cutlery basket with the handles facing downwards.

If the handles protrude from the bottom of the basket, obstructing the lower spray arm, load the cutlery with the handles facing upwards.

Mix spoons with other cutlery to prevent them from sticking together.

Silver cutlery tends to go black if mixed with steel cutlery. Place it in the cutlery basket separate from the others.

The cutlery basket is in two parts which can be separated to give greater loading flexibility. To separate the two parts, slide them horizontally in opposite directions and pull them apart.
To reassemble, reverse the procedure.



## The upper basket

The upper basket is designed for plates (dessert plates, saucers, dinner plates of up to 25 cm in diameter), salad bowls, cups and glasses.

Arrange items on and underneath the fold-down cup racks so that water can reach all surfaces.

Light items (plastic bowls etc.) should be loaded in the upper basket and arranged so they do not move.


US47

### *In case that plates are loaded in the upper basket:*

*load them starting from the rear posiitons of the basket; tilting them slightly forwards and avoiding the front positions near the door.*


US71

**Before closing the door, ensure that the spray arms can rotate freely.**

## Adjusting the height of the upper basket

If washing very large plates (over 27 cm and up to 32 cm in diameter) you can load them in the lower basket after moving the upper basket to the higher position.



RC01

**To move to the higher position proceed as follows:**

1. Move the front runner stops (A) of the upper basket outward and slide the basket out.
2. Refit the basket in the higher position and replace the stops (A) in their original position.

**When the top basket is in the higher position it will only take plates up to 20 cm in diameter and you will not be able to use the cup racks.**

**After loading your machine always close the door, as an open door can be a hazard.**

# Hints for test centres

Before starting any test it is necessary to fill completely with salt the salt container and with rinse aid the rinse aid dispenser.

| | |
|---|---|
| Test standard: | EN 50242 |
| Reference programme: | Bio 50°C |
| Load: | 12 standard place settings |
| Rinse aid selector: | position 5 |
| Detergent dosage: | 25 g in the dispenser<br>5 g on the dispenser lid |

Arrangement upper basket

Arrangement cutlery basket

Arrangement lower basket

## Technical specifications

| | | |
|---|---|---|
| Dimensions | Width<br>Height with worktop<br>Height without worktop<br>Max depth<br>Max depth with open door | 60 cm<br>85 cm<br>82 cm<br>63.5 cm<br>115.2 cm |
| Electrical connection<br>Motor rating during wash<br>Power of heating element<br>Overall power | Voltage | 230 V - 50 Hz<br>200 W<br>2100 W<br>2300 W |
| Water supply pressure | Minimum<br>Maximum | 50 kPa (0.5 bar)<br>800 kPa (8 bar) |
| Water supply connection | Water cold/hot | max. 60°C |
| Capacity | | 12 place settings |

## Fitting under a counter

(kitchen worktop or sink)

By removing the machine's worktop, you can install it under a close fitting sink unit or a pre-existing top, providing the dimensions of the recess correspond to those shown in the picture.

**Proceed as follows:**

- Remove the machine's worktop by unscrewing the two rear retaining screws, pull from the front and slide out the rear slots, lifting the worktop.

Insert the machine after adjusting height and levelling with the adjustable feet. When inserting the machine, ensure that the water inlet and drain hoses are not kinked or squashed.




## Levelling

Good levelling is essential for correct closure and sealing of the door.

When the appliance is correctly levelled, the door will not catch on the levelling spacers on either side of the cabinet.

If the door does not close correctly, loosen or tighten the adjustable feet until the machine is perfectly level.

***From the Electrolux Group.*** *The world's No.1 choice.*

*The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. 14 billion USD in more than 150 countries around the world.*